

ASSEMBLY INSTRUCTIONS FOR YOUR RICO ESPINET ARIAL PENDANT

IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- * **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- * Turn off power at switch before replacing bulbs
- * If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.
- * This fixture is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts carefully from the carton. Do not throw away any parts.
3. Remove mounting plate (B) from canopy (D) by unthreading screws (E). Set screws (E) aside.
4. Affix mounting plate (A) to ceiling outlet box using mounting plate screws (C).
5. Measure desired drop for fixture to hang and add/remove extension tubes (G) to reach desired position. Guide wiring through extension tubes before threading tubes together. ****TO ADD/ REMOVE EXTENSIONS:** (Un)Thread the threaded tube of one extension out of/ into the threaded opening of the next extension. Make sure wiring is pulled tight when threading extensions together to prevent damage to the wire.**
6. Thread bottom extension tube (G) onto threaded tube (H).
7. Carefully guide wire up through hang straight (F) and canopy (D). Thread hang straight (F) onto top extension (G).
8. Cut the cord to the desired length to make electrical connections. Note: At least 8 inches of wire is needed to make proper electrical connections.
9. Lift fixture to ceiling and make proper electrical connections noted in steps 10-12. A LICENSED ELECTRICIAN IS RECOMMENDED.
10. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
11. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
12. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
13. Carefully push wire connections back into ceiling outlet box.
14. Aligning holes in canopy (D) and mounting plate (B), slide canopy over mounting plate and hold flush against ceiling. To secure position of canopy (D), thread screws (E) back into mounting plate.
15. Remove screws (K) from metal frame (J). Set screws (K) aside.
16. Slide glass shade (L) over socket housing (I), so it sits under metal frame (J).
17. Align holes in glass shade (L) with holes in metal frame (J). Secure glass shade (L) by threading screws (K) through holes in metal frame (J) and into holes in glass shade (L). Note: Do not over tighten as this could cause damage to glass.
18. Install one 100W MAX. Type A, medium base bulb into the socket located inside socket housing (I).
19. Reconnect main electrical supply at the fuse box/ circuit breaker and test fixture.

